



WIRELESS N 150 HOME ROUTER **DIR-600**

QUICK INSTALLATION GUIDE

CONTENTS OF PACKAGING

CONTENTS



INSTALLATION CD
Includes set-up WIZaRd & technical manuals

WIRELESS N 150 HOME ROUTER
DIR-600

POWER ADAPTER
adapteR

ETHERNET CABLE (CAT5 UTP)
connect tHe RouteR to YouR pc duRInG set-up

If any of these items are missing from your packaging contact your reseller

PRODUCT SETUP

ENGL

CD SETUP WIZARD



SET-UP WIZARD CD

the cd contains all of the instructions required to set-up DIR-600



INSERT CD

Insert the cd into the cd drive of your computer. the set-up wizard should start automatically. make sure that your internet connection is active. (do not plug in DIR-600 yet)



SET-UP WIZARD

select your language from the list of options and follow the steps within the wizard to complete the set-up of DIR-600

ADVANCED SET-UP (ACCESS VIA IP ADDRESS)

to configure DIR-600 manually (without the set-up cd) connect your computer to the DIR-600 using the ethernet cable provided. then connect the power cable on the DIR-600. the power light will display as solid blue.

then simply open a browser window and enter the Ip address in the browser address field:

Ip address: http:// dlinkrouter or http://192.168.0.1

useRname: admin

passWoRd:

TROUBLESHOOTING

SET-UP AND CONFIGURATION PROBLEMS

1. HOW DO I CONFIGURE MY DIR-600 ROUTER WITHOUT THE CD, OR CHECK MY WIRELESS NETWORK NAME (SSID) AND WIRELESS ENCRYPTION KEY?

- connect your pc to the router using an ethernet cable.
- open a web browser and enter the address <http://dlinkrouter> or <http://192.168.0.1>
- the default username is 'admin'. the default password is " (leave the field blank).
- If you have changed the password and can not remember it, you will need to reset the router to set the password back to " (leave the field blank).

2. HOW DO I RESET MY DIR-600 ROUTER TO FACTORY DEFAULT SETTINGS?

- ensure the router is powered on.
- press and hold the reset button on the rear of the device for 20 seconds.
note: Resetting the router to factory default will erase the current configuration settings. to re-configure your settings, log into the router as outlined in question 1, then run the setup Wizard.

3. HOW DO I ADD A NEW WIRELESS CLIENT OR PC IF I HAVE FORGOTTEN MY WIRELESS NETWORK NAME (SSID) OR WIRELESS ENCRYPTION KEY?

- every pc that needs to connect to the router wirelessly, you will need to ensure you use the correct Wireless network name (ssid) and encryption key.
- use the web based user interface (as described in question 1 above) to check or choose your wireless settings.
- make sure you write down these settings so that you can enter them into each wirelessly connected pc. You will find a dedicated area on the back of this document, this important information for future use.

4. WHY CAN I NOT GET AN INTERNET CONNECTION?

- For cable users make sure clone mac address option is ticked during Wizard installation (or enter the registered mac) and make sure the service has been enabled/connected and is operational.
- For adsl users please contact your lisp to make sure the service has been enabled/connected by your lisp and that your lisp username and password is correct.

TECHNICAL SUPPORT

ENGL

You can find software updates and user documentation on the d-link website.

Tech Support for customers in

Australia:

tel: 1300-766-868
24/7 technical support
Web: <http://www.dlink.com.au>
e-mail: support@dlink.com.au

India:

tel: 1800-233-0000 (mtnl & Bsnl toll Free)
+91-832-2885700 (Gsm, cdms & others)
Web: www.dlink.co.in
e-mail: helpdesk@dlink.co.in
techsupport@dlink.co.in

Indonesia, Malaysia, Singapore and Thailand:

tel: +62-21-5731610(Indonesia)
tel: 1800-882-880(malaysia)
tel: +65 6501 4200(singapore)
tel: +66-2-719-8978/9(thailand)
24/7, for english support only
Web: <http://www.dlink.com.sg/support/>
e-mail: support@dlink.com.sg

Korea:

tel: +82-2-2028-1815
monday to Friday 9:00am to 6:00pm
Web: <http://www.d-link.co.kr>
e-mail: arthur@d-link.co.kr

New Zealand:

tel: 0800-900-900
24/7 technical support
Web: <http://www.dlink.co.nz>
e-mail: support@dlink.co.nz

Egypt:

tel: +202-2919035
+202-2919047
sunday to thursday 9:00am to 5:00pm
Web: <http://support.dlink-me.com>
e-mail: support.eg@dlink-me.com

Iran:

tel: +98-21-88721415
saturday to thursday 9:00am to 5:00pm
Web: <http://Tolirayan.com>
e-mail: support.ir@Tolirayan.com

TECHNICAL SUPPORT

You can find software updates and user documentation on the d-link website.

Tech Support for customers in

Iran:

tel: +98-21-88721415
saturday to thursday 9:00am to 5:00pm
Web: <http://Tolirayan.com>

Pakistan:

tel: +92-21-4548158
+92-21-4548310
monday to Friday 10:00am to 6:00pm
Web: <http://support.dlink-me.com>
e-mail: zkashif@dlink-me.com

South Africa and Sub Sahara Region:

tel: +27-12-665-2165
08600 dlnk (for south africa only)
monday to Friday 8:30am to 9:00pm south africa time
Web: <http://www.d-link.co.za>
e-mail: support@d-link.co.za

Turkey:

tel: +90-212-2895659
monday to Friday 9:00am to 6:00pm
Web: <http://www.dlink.com.tr>
e-mail: turkiye@dlink-me.com

U.A.E and North Africa:

tel: +971-4-4278127 (u.a.e)
sunday to thursday 9.00am to 6.00pm Gmt+4
Web: <http://www.dlink-me.com>
e-mail: support.me@dlink-me.com

Saudi ARABIA (KSA):

tel: +971-4-4278127 (u.a.e)
sunday to thursday 9.00am to 6.00pm Gmt+4
Web: <http://www.dlink-me.com>
e-mail: support.me@dlink-me.com